



FEATURES

- High-power 500 lumen white Luxeon LED
- Industrial corrosion resistant polymer body
- Aircraft grade aluminium head
- Ultra smooth reflector for long distance beam
- 3 Light mode settings
- Soft & hard touch switch for easy mode selection
- IP68 dust & water proof
- 2 metre submersible (30 mins)
- 2 metre drop resistant
- Useful built-in pocket clip
- Nylon safety wrist strap included

BATTERY - 2 x AA 1.5v Duracell Alkaline Batteries (Included)

WEIGHT - 74g [with batteries]

DIMENSIONS - Ø30mm x 155mm

ADVICE & IMPORTANT INFORMATION!

Only use high-quality Alkaline batteries or Ni-MH rechargeable batteries. DO NOT USE rechargeable LITHIUM batteries, these will damage your flashlight as they exceed rated voltage.

Do not use batteries of different brands or mix old and new batteries. Please recycle used batteries responsibly.

Battery life is affected by different battery brands, different ambient temperatures and different lighting modes.

If the batteries are installed and the flashlight does not work, try checking for the following: (1) Press the switch button several times. (2) Check that the batteries are inserted the correct way around according to polarity markings. (3) Check there is no debris on the contacts that might affect the battery connection. (4) Check there is no water or dampness in the flashlight, if so, allow it to fully dry out and try again.

Do not look directly at the LED.

Do not operate in direct sunlight or extreme temperature conditions (below -10°C or above 40°C).

The LED and aluminium head will become warm/hot when switched on; do not touch and do not place face down on any surface – risk of fire!

Do not use the device if there is any visible damage to the housing, head, switch or lens.

Children under 12 years of age should only use the product under adult supervision.

ANSI FL 1 Standard



Mode	Lumens	Distance	Runtime
HIGH	500 Lumens	177M	4½ H
MID	175 Lumens	122M	8 H
LOW	25 Lumens	48M	35 H

OPERATION

Switch Sequence: HIGH > OFF > MID > OFF > LOW > OFF

Hard Touch Switch - press switch until it clicks to turn the light OFF between each mode.

Soft Touch Switch - when the light is on, press switch gently without it clicking for quick-fire mode selection without turning OFF between each mode.

[If left in any mode for over 3 seconds, the next press will turn off]



Do not open, disassemble or attempt to modify the product; this will void the warranty and can be dangerous. Improper use or modification is not covered under the warranty.

Take care not to let the lenses come into contact with hard/sharp objects, damage/scratches to the lens will affect light output.

If you are not using the product for long periods of time (3 weeks or more), remove the batteries to prevent battery leakage and battery depletion. Battery leaks are not covered under warranty.

Protect batteries from heat, intense sunlight, fire, water and moisture – danger of explosion!

If batteries are damaged, fluids can leak out. AVOID contact as this can lead to skin irritation and/or burns. If skin contact happens, rinse thoroughly with water. If irritation persists, seek medical advice. Seek immediate medical assistance if battery fluid comes into contact with the eyes.

This product has a 1 year standard warranty (or extended to 2 years once registered online at WWW.UNILITE.CO.UK) against manufacturing faults and defects. It does not cover normal wear and tear, modifications, accidental damage or poor maintenance. Unilite warranties do not cover battery leaks or the use of incorrect chargers and cables that can damage batteries.

Do not dispose of this device in normal household waste. It must be disposed of via an authorised disposal centre or at your local waste disposal unit.

Please recycle or re-use packaging where possible.

Keep these instructions for future reference or for subsequent possessors.

